

Accessories for shear box

Box model 27-	WF0215/B	WF0216/B	WF0217/B	WF0218/B	WF0219/B	WF0222/B
Part description27-						
Sample cutter*	WF0215/B7	WF0216/B7	WF0217/B7	WF0218/B7	WF0219/B7	WF0222/B7
Extrusion dolly*	WF0215/8	WF0216/8	WF0217/8	WF0218/8	WF0219/8	WF0222/8

Spare parts for shear box assemblies

Box model 27-	WF0215/B	WF0216/B	WF0217/B	WF0218/B	WF0219/B	WF0222/B
Part description 27-						
Loading pad	WF0215/B2	WF0216/B2	WF0217/B2	WF0218/B2	WF0219/B2	WF0222/B2
Retaining plate	WF0215/B3	WF0216/B3	WF0217/B3	WF0218/B3	WF0219/B3	WF0222/B3
Porous plate	WF0215/4	WF0216/4	WF0217/4	WF0218/4	WF0219/4	WF0222/4
Plane grid**	WF0215/B5	WF0216/B5	WF0217/B5	WF0218/B5	WF0219/B5	WF0222/B5
Perforated grid**	WF0215/B6	WF0216/B6	WF0217/B6	WF0218/B6	WF0219/B6	WF0222/B6

*Not supplied with the shear box. To be ordered separately

**Two pieces supplied with the shear box